

Examples of Commercial Aircraft in the U.S.

Wide-body Aircraft	Narrow-Body Aircraft
<p>Examples: Airbus A330 (pictured) Boeing 767 Boeing 777</p> 	<p>Examples: Boeing 737 (pictured) Boeing 757 Airbus A320</p> 
Regional Jets	Regional Turboprops
<p>Examples: Bombardier CRJ 200 (pictured) Embraer 135/145 Embraer 170/190</p> 	<p>Examples: Bombardier Dash 8 Q400 (pictured) Embraer 120 Beechcraft 1900</p> 

Photo Source: Northwest Air Service Initiative Handbook